

## Table of Contents

Section	Page
<b>1. Overview</b>	<b>1</b>
1-1 Introduction	1
1-1-1. Definition	1
1-1-2. Features	1
1-2. Hardware Structure	3
1-2-1. Partial Names and Functions	3
1-2-2. System Configuration	4
1-3. Procedures to prepare for starting operation	5
1-4. Types of Tag functions	6
<b>2. Specifications</b>	<b>7</b>
2-1. General specifications	7
2-2. Performance specifications	7
2-3. Auxiliary I/O Specifications	7
2-3-1. Input Specification	7
2-3-2. Output Specification	8
2-3-3. Auxiliary I/O pin assignment	8
2-4. Communication Specification	8
2-4-1. Datalink Communication	8
2-4-2. Serial communication	8
2-5. Installation	9
<b>3. The structure of the main menu in PMU main unit</b>	<b>10</b>
3-1. Diagnosis	11
3-1-1. Screen Check	11
3-1-2. Communication Check	12
3-1-3. System Check	14
3-1-4. Memory Check	15
3-1-5. Alarm History	16
3-2. Setup	18
3-2-1. Run mode Setup	19
3-2-2. Communication Setup	19
3-2-3. System Setup	21
3-2-4. Memory Initialization	22
3-2-5. Alarm Initialization	22
3-3. Transfer	23
3-4. Run	24

## [Appendix]

<b>A. SYSTEM BUFFER</b>	25
A-1. Definition	25
A-2. System buffer Map	25
A-3. Description of System buffer	26
<b>B. Application examples</b>	28
B-1. PLC Communication specification	28
B-1-1. PLC Types and communication method	28
B-1-2. Setup items	28
B-1-2-1. Serial setup items (1:1 Comm.)	28
B-1-2-2. Data Link setup items	29
B-2. PLC Communication flow chart.	30
B-3. Connection to PLCs	31
B-3-1-2. Master-K 10S, 30S, 60S, 100S, K10S1, K60H, K200H	35
B-3-1-2-1. PMU main unit Setup	35
B-3-1-2-2. PLC Setup	35
B-3-1-2-3. PLC Address allocation table(Master-KS/H Series)	36
B-3-1-2-4. Cable connection (PMU $\leftrightarrow$ PLC)	36
B-3-1-3. GLOFA-GM Cnet Setup	36
B-3-1-3-1. PMU main unit setup	36
B-3-1-3-2. PLC Setup	37
B-3-1-3-3. PLC Address allocation table (GLOFA-GM)	38
B-3-1-3-4. Cable connection (PMU $\leftrightarrow$ PLC)	38